reckey

Bluetooth® Connected Keychain

LOCATE FIND CONTROL

Quick Start Guide

roadeyescams

1 Battery installation

Before starting using **recKEY**, you must first install the battery as indicated below:



- Open back-cover (Picture 1).
- Take out the battery: insulation protection film (if inside, option).
- Check model number of battery should be 2032. Insert it into the recKEY with correct downwards of battery negative pole. (Picture 2).
- Make sure battery is OK and recover back cover. You can use it now.
- Reconnection is needed after battery change.

2 Download recKEY app

To set up **recKEY** using your mobile device, you first need to get **recKEY app**.

Search for **recKEY app** in the in the App store, Google Play or Windows Phone store, download and install the App on your mobile device.

Available on the App Store

ANDROID APP ON Google play

Download from Windows Phone Store

System Requirements

iOS

iOS 7 + devices with Bluetooth 4.0 BLE IPhone 4s, 5, 5C, 5S, 6, 6Plus, IPad (3th,4th and 5th gen) IPad Mini, Ipod touch (5th gen)

Android

Select Andoid 4.3 + devices that support Bluetooth 4.0 BLE

Windows Phone

Select Windows Phone 8.1 that support Bluetooth 4.0 BLE

Make sure Bluetooth is enabled on your mobile device

3 How to use recKEY



PRESS BUTTON x 1

Save your position in recKEY application

PRESS BUTTON x 1

when camera feature is on in recKEY app
Remotely control your smartphone camera to take a picture or a selfie

PRESS AND HOLD BUTTON

Make your smartphone ring to easily find it

4 Homepage


52%
15:47
recKEY
1
Île du Pont
Pont de Neuilly
Boulevard du Général Leclerc
A
D1
N13
Boulevard du Général Koenig
Rue du Général Lanrezac
La Seine
Google
Notification Appels
Caméra
Partage position
Trouver-moi

Search & Pair display connection status and number of connected devices. Tap to pair a recKEY. Access list of connected devices or discoverable devices

Advanced settings access your account, help and about us sections

Location The blue dot refers to your current location; the red dot indicates location saved. Press the red dot to share or delete the location saved

Call Notifications Press to enable / disable incoming call notifications

Camera Remote Click here to take photos remotely with your recKEY

Location sharing Press to share your location with your friends via social networks applications already installed on your smartphone.

Find me Click here to find your connected device

5 Pairing

Press the search key on the top right of the main page to access the search page of your recKEY. Then find and select your recKEY, the latter can be paired/ unpaired as needed.



	Pair or unpair all detected recKEYs
recKEY	**Customized** name of paired recKEY
Déconnecté 〉	**Status** of detected recKEY
Search button	**Search** discoverable recKEYs

6 Settings

Click here to add or edit your device picture



Status
recKEY status (connected or disconnected)

Device name
Customize your recKEY's name

Battery level
Indicates your recKEY's battery level

Ringtone
Change the ringtone of your recKEY

Volume
Increase or lower the volume of your recKEY's ringtone

Alarm distance
Control the distance to trigger the alarm of your recKEY

Tracker
Enable or disable this feature to keep track of the itinerary of the locations saved

History
Click here to access the history of the locations saved

Unpair
Unpair the recKEY currently connected

7 Advanced settings

From recKEY app homepage, press this key to access the advanced settings



Account
Your personal account information

Help
Check our FAQ and get help from our RoadEyes support team

About
Learn more about our product and company

SCAN FOR
MORE LANGUAGES

Scansionare per ottenere più lingue
Digitalizar para obtermais línguas
Escanear para obtener más idiomas
Scannen, um anderen Sprachen erhalten
Scan om meer talen te krijgen
Daha fazla dil almak için tarama
Skanowanie, aby uzyskać więcej języków
için scanare pentru a obține mai multe limbi
сканирование, чтобы получить больше языков
请扫描二维码以获取 更多语言翻译。
掃描QR碼 獲得更多的語言
より多くの言語を取得す るためにスキャン
สแกนเพื่อให้ได้ภาษามากขึ้น
더 많은 언어를 얻기 위해 검색

OR VISIT

www.road-eyes.com/assets/reckey-userguide.pdf

TO DOWNLOAD OUR MULTI-LANGUAGE USER MANUAL

Warning

• Negative pole of battery must be downwards.
• Battery cannot be recharged. Please properly handle waste battery.
• Please keep the device dry, rigorous immersion or long-term storage and use in damp environment will cause permanent damage.
• Prohibit any contact with sharp, hard objects, and avoid the cover glass or other rupture, causing accidental injuries.
• This product is only compatible with iPhone 4s and newer, select Android 4.3 + and Windows Phone 8.1 + mobile devices with Bluetooth 4.0 BLE connectivity.
• Environment of battery cannot support high-temperature. Remove battery when not used for a long time.
• Follow local legal use of wireless products 2.4GHz

About this manual

The features of recKEY and the content of the user manual are subject to change. To get the latest instructions on how to use this product, please refer to the online user manual available on our website: www.road-eyes.com

reckey

Porte clefs connecté en Bluetooth®

LOCALISER TROUVER CONTRÔLER

Manuel d'utilisation rapide

roadeyescams

1 Installation de la pile

Avant de commencer à utiliser le **recKEY**, vous devez insérer la pile comme suit :



ILLUSTRATION 1 ILLUSTRATION 2

- Ouvrez le couvercle arrière (illustration 1)
- Retirez le film de protection de la pile (en option).
- Vérifiez que le numéro de modèle de la pile est bien le 2032, puis insérez-la dans le recKEY en prenant garde d'orienter la borne moins vers le bas. (Illustration 2).
- Assurez-vous que la pile est bien en place avant de remettre en place la couvercle arrière. L'appareil est maintenant prêt à être utilisé.
- Une reconnexion est nécessaire à chaque changement de pile.

2 Télécharger l'application recKEY

recKEY fonctionne avec votre téléphone mobile, vous devez d'abord obtenir **l'application recKEY**.

Cherchez **l'app recKEY** dans l'App Store, le Google Play ou le Windows phone store, puis téléchargez et installez la sur votre téléphone.

Télécharger dans l'App Store

APPLI ANDROID SUR Google play

Télécharger sur Windows Phone Store

Compatibilité

iOS

iOS 7 ou supérieur avec Bluetooth 4.0 BLE, iPhone 4s, 5, 5c, 5s, 6, 6 Plus, iPad (3ème, 4ème et 5ème gen) iPad Mini, iPod touch (5ème gen))

Android

Certains Android 4.3 ou supérieur avec Bluetooth 4.0 BLE

Windows Phone

Certains Windows Phone 8.1 avec Bluetooth 4.0 BLE

Assurez-vous que la connexion Bluetooth soit activée sur votre appareil mobile

3 Comment utiliser recKEY ?



APPUYEZ SUR LE BOUTON 1 X

Enregistrer votre position dans l'application recKEY

APPUYEZ SUR LE BOUTON 1 X

Lorsque le mode « Caméra » est activé dans l'application recKEY, appuyez une fois sur le bouton pour prendre une photo ou un selfie

MAINTENEZ APPUYÉ LE BOUTON

Faites sonner votre smartphone pour le retrouver facilement

4 Page d'accueil



Rechercher & Jumeler État de connexion et nombre d'appareils connectés. Appuyez ici pour connecter votre recKEY. Accéder à la liste d'appareils détectés

Paramètres avancés accéder à votre compte, la rubrique aide et à propos

Localisation désigne votre position actuelle; le point rouge désigne la position mémorisée. Appuyez sur le point rouge pour partager ou effacer la position mémorisée.

Notifications d'appels Appuyez ici pour activer/désactiver les notifications d'appels entrants

Déclencheur photo Appuyer ici pour prendre des photos à distance avec votre recKEY.

Partage position Appuyez ici pour partager votre position géo-localisée avec vos amis via les applications de réseaux sociaux déjà installées sur votre smartphone.

Trouver-moi Appuyez ici pour retrouver votre dispositif connecté.

5 Jumelage

Appuyez sur le bouton en haut à droite de l'écran d'accueil pour accéder à la page de recherche de votre recKEY. Ensuite recherchez et sélectionnez votre recKEY, ce dernier pourra être activé/désactivé selon vos besoins.



	Connecter/déconnecter tous les recKEYs détectés.
recKEY	**Nom personnalisable** du recKEY connecté.
Déconnecté 〉	**Statut** du recKEY détecté.
Recherche	**Recherche** Appuyez ici pour rechercher les dispositifs disponibles en temps réel.

6 Réglages

Cliquez ici pour télécharger ou prendre une photo depuis votre smartphone



Statut
Statut du recKEY (connecté ou déconnecté)

Nom de l'appareil
Personnaliser le nom du recKEY connecté

Niveau de batterie de votre recKEY
Indique le niveau de batterie de votre recKEY

Sonnerie
Appuyez ici pour modifier la sonnerie de votre recKEY

Volume
Appuyez ici pour augmenter ou diminuer le volume de la sonnerie de votre recKEY.

Distance Alarme
Appuyez ici pour gérer la distance que vous souhaitez pour déclencher l'alarme de votre recKEY

Tracker
Appuyez ici pour activer/désactiver cette fonction qui vous permettra de suivre les itinéraires des positions mémorisées

Historique
Appuyez ici pour découvrir l'historique de vos positions enregistrées

Déconnecter
Déconnecter le recKEY actuellement connecté

7 Paramètres avancés

Depuis la page d'accueil de l'application recKEY, appuyez sur ce bouton pour accéder aux paramètres avancés



Compte
Appuyez ici pour voir l'état de votre compte, et avec quelle adresse e-mail vous êtes connecté sur cette application. Ainsi, vous pouvez le déconnecter manuellement.

Aide
Appuyez ici pour accéder à une plateforme d'aide dédiée aux fonctionnalités du recKEY.

A propos
Appuyez ici pour trouver les informations concernant notre marque et nos produits.

SCANNER POUR
PLUS DE LANGUES

Scansionare per ottenere più lingue
Digitalizar para obtermais línguas
Escanear para obtener más idiomas
Scannen, um anderen Sprachen erhalten
Scan om meer talen te krijgen
Daha fazla dil almak için tarama
Skanowanie, aby uzyskać więcej języków
için scanare pentru a obține mai multe limbi
сканирование, чтобы получить больше языков
请扫描二维码以获取 更多语言翻译。
掃描QR碼 獲得更多的語言
より多くの言語を取得す るためにスキャン
สแกนเพื่อให้ได้ภาษามากขึ้น
더 많은 언어를 얻기 위해 검색

OU RETROUVEZ NOUS SUR

www.road-eyes.com/assets/reckey-userguide.pdf

POUR TÉLÉCHARGER LE MANUEL MULTILINGUES

Avertissement

• La borne moins de la pile doit être orientée vers le bas.
• La pile n'est pas rechargeable. Merci de recycler correctement les piles usagées.
• Tenez l'appareil au sec, ne l'immergez pas, rangez-le à l'abri de l'humidité et ne l'utilisez pas dans un environnement humide, cela risque de l'endommager durablement.
• Evitez que l'appareil n'entre en contact avec des objets durs et tranchants, protégez le couvercle en verre de l'appareil de tout dommage qui pourrait provoquer un accident ou vous blesser.
• Ce produit est uniquement compatible avec l'iPhone 4S ou supérieur, certains appareils Android 4.3+ ou Windows Phone 8.1 équipés de Bluetooth 4.0 BLE
• La pile ne doit pas être exposée à des températures extrêmes. Retirez la pile en cas d'inutilisation prolongée de l'appareil.
• Respectez les lois locales applicables aux produits sans fil 2,4 GHz.

A propos de ce manuel

Les fonctionnalités de recKEY et le contenu de ce manuel utilisateur sont susceptibles d'être modifiés. Pour obtenir les dernières instructions sur l'utilisation de ce produit, veuillez vous référer au manuel disponible sur notre site internet: www.road-eyes.com

EUROPEAN UNION
CE DIRECTIVE

Declaration of conformity with regard to the EU Directive 1999/5/EC. RoadEyes SAS declares that this device is in compliance with the essential requirements and other relevant provisions of the R&TTE Directive 1999/5/EC. The complete declaration of conformity is available on request via our customer service: support@road-eyes.com

Déclaration de conformité à l'égard de la directive européenne 1999/5/CE. RoadEyes SAS déclare que cet appareil est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive R&TTE 1999/5/CE. La déclaration de conformité complète est disponible sur demande auprès de notre service client: support@road-eyes.com

DISPOSAL AND RECYCLING INFORMATION

After the implementation of the European Directive 2002/96/EU in the national legal system, the following applies: Electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic devices at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilizing old devices, you are making an important contribution to protecting our environment.

Les marques citées sont des marques déposées par leur fabricant respectif. Photos et caractéristiques non contractuelles. All brands of product names are or may be trademarks of their respective owners. Pictures and specifications are not contractual.
Made in China. ©2015 RoadEyes SAS, all rights reserved.
RoadEyes SAS, 168 avenue Charles de Gaulle, 92200 Neuilly/Seine, France.

reckey

www.road-eyes.com